

Hydro-Tech M8200 Multibeam Echo Sounder User Manual

Beijing Hydro-Tech Marine Technology Co., Ltd.

V1.6 Sep. 2022

Copyright

This manual including the products and software mentioned in it belong to copyright 2022 of Beijing Hydro-Tech Marine Technology Co., Ltd. Without the written permission of Hydro-Tech, the manual and its relevant parts shall not be copied or reprinted in any pattern.

Customer Supports

Welcome to contact us at any time. We would feedback in time and provide good service to you. Below is the contact information.

Beijing Hydro-Tech Marine Technology Co., Ltd.
1F Building 5, No. 33 Jingsheng South 2nd Street,
TongzhouDist, Beijing, China
Postcode: 101102
Tel: 010-57136778
Fax: 010-67870776
Website: www.hydro-tech.cn

Table of Contents

1.	Introduction.....	1
1.1.	Product Introduction.....	1
1.2.	How to Use This Manual.....	2
2.	System Specifications.....	3
2.1.	System Specifications.....	3
2.2.	Physical Specifications	3
2.3.	Electrical Specifications	4
2.4.	Compatible Software	4
2.5.	Auxiliary Measuring Devices.....	4
3.	Safety	5
3.1.	Equipment Safety	5
3.2.	Maintenance	5
4.	Acoustic Transducer Operation.....	6
5.	Sonar Interface Module Operation	7
5.1.	Sonar Interface Module Introduction	7
5.2.	Sonar Interface Module Connecters and Indicators	8
5.2.1.	Front Panel.....	8
5.2.2.	Back Panel	8
6.	System Installation and Configuration.....	11
6.1.	Underwater Parts Installation.....	11
6.1.1.	Underwater Transducer Installation	12
6.1.2.	Underwater Installation Precautions	12
6.2.	Sonar Interface Module Installation.....	13
6.2.1.	Sonar Interface Module Introduction	13
6.2.1.	Sonar Interface Module Installation	17
7.	How to set up RTK?.....	18
7.1.	How to use NTRIPClient.....	21
7.2.	COM Port Setting	21
7.3.	NTRIP Setting.....	22
7.4.	Check the Internal GPS Status	24
	Appendix 1 Underwater Transducer Drawing	25
	Appendix 2 Sonar Interface Module (Deck Unit) Drawing	26
	Appendix 3 Sonar Wet Cable Definition.....	27

1. Introduction

1.1. Product Introduction

MS8200, which is also named as Hercules, is a new generation of multibeam echo sounder that is specially designed for professional oceanographic mapping and deep channel surveying. It is based on the new product platform that our R & D team developed after so many years of sounding technology accumulation and studying the advantages & shortcoming of various models using under diversified environments.

MS8200 is not only of reliable quality, but also with most advanced technologies. It can work well in harsh environment, that is why so many customers trust it and MS8200 won a lot of praises. MS8200 deserves it!

MS8200 multibeam echo sounder mainly consists of underwater acoustic transducer and sonar interface module. Below is the system diagram shown in Figure 1.1.




Figure 1.1 System Diagram

It works together with system software, including display and control software named “HydroQuest” and navigation & data acquisition software named “HydroNavi”. And its data is compatible with Hypack post processing too.

1.2. How to Use This Manual

This manual introduces main technical specification, system framework, functions, installation, operation and safety precautions of MS8200 multi beam echo sounder system. It is recommended that users had better read this manual carefully before installing or operating the equipment to avoid unnecessary injury to equipment and personnel.

- (1) For the users who use MS8200 for the first time, please read this manual Part 3. Safety to prevent any damage to equipment or injury to personnel during wrong operation;



- (2) For the users who use MS8200 for the first time, please refer to Part 6. System Installation and Configuration instructions. Furthermore, Appendix 1 and Appendix 2 show the product mechanical drawings and related installation mount & other components.
- (3) If you have known or used MS8200 multibeam echo sounder before, you can directly read the manual of Hydro-Quest to learn how to display and control MS8200.

2. System Specifications

2.1. System Specifications

Working Frequency	200kHz
Depth Resolution	0.75cm
No. of Beams	512
Working Modes	Equiangular or Equidistance
Cross Track Beam Width	1°
Along Track Beam Width	2°
Max. Ping Rate	60kHz
Signal Type	CW or Chirp
Swath Sector	160°
Pulse Width	15 μ s ~ 8ms
Sounding Range	0.4~400m
Max. Working Depth	50m
Near Field Focus	Yes
Water Column Image	Yes
Realtime Roll Stabilization	Yes

2.2. Physical Specifications

Receiving Transducer Size	500 x 457 x 147mm
Transducer Weight	22.6kg
Sonar Interface Module Size	200mmx145mmx75.5mm
Sonar Interface Module Weight	1.8Kg
Working Temperature	-2°C ~ 40°C
Storage Temperature	-20°C ~ 55°C

2.3. Electrical Specifications

Power Supply	DC10V-32V AC110V-240V
Power Consumption	60W (Standard) 40W (Low Consumption Mode)
Data Interface Port	Ethernet
Synchronization Output	5V TTL
Auxiliary Device Port	RS232
Deck Cable Length	8m or Customized

2.4. Compatible Software

- ◆ HydroQuest: Display and Control Software;
- ◆ HydroNavi: Navigation and Data Collection Software;
- ◆ Compatible with Hypack data collection software and Hypack & Caris post processing software.

2.5. Auxiliary Measuring Devices

- ◆ Sound Velocity Sensor: Optional for SVS1500
- ◆ Sound Velocity Profiler: Optional for SVP1500
- ◆ INS: Optional for external IMU POS25/15/08

3. Safety



In order to ensure the personal and equipment safety during MS8200 operation, please read the following details before operation.

3.1. Equipment Safety

- (1) During transportation, please pack the transport box properly and avoid any possible damage of vibration;
- (2) Check whether the transporting carton is damaged before unpacking
- (3) Check whether each part of the system is damaged before installation;
- (4) Main unit or transducer and other accessories shall not be dropped down;
- (5) It is forbidden to plug or unplug any connecting cable during equipment working operation;
- (6) All plug-in or unplug cables of sonar interface module shall not be exposed to rain or water;
- (7) The sonar interface module shall not be exposed to rain or water to prevent any damage to internal electrical components;
- (8) When underwater transducer is not put into water, the whole sounding system shall not be powered on for testing or any other operation;
- (9) It is forbidden to place the underwater transducer directly downward to the ground without protection, especially it is forbidden to scratch the surface of transducer part with hard or sharp objects;
- (10) All cables of the system shall not be folded, pressed, squeezed, pulled, cut or other operations that may cause physical injury;
- (11) Not exceed the operating and storage temperature limits;

3.2. Maintenance

When using or storing acoustic transducers, please adapt the following steps to protect it for better maintenance:

- (1) Cleaning: clean with mild and clean fresh water, and soft brush the outside if needed.
- (2) Wash the underwater transducer with fresh water after operation each time;
- (3) It is forbidden to use any antifouling paint to coat the acoustic transducer;
- (4) It is forbidden to expose the surface of the transducer under the sun to prevent any damage to the transducer;

4. Acoustic Transducer Operation

The appearance of acoustic transducer and mounting flange of MS8200 multibeam echo sounder is shown in Figure 4.1.




Figure 4.1 MS8200 Acoustic Transducer

The direction indicated by the yellow arrow is the forward direction of sounding measurement. When installing the transducer, pay attention to its direction. The watertight cable is drawn from the center hole at the backside and passes through the connecting flange. Design the adapter flange and installation according to the actual situation of the surveying ship and the mechanical drawing of the acoustic transducer (See Appendix 1). Connect with the bracket to fix the acoustic transducer on the measuring boat or mounting pole.

5.2. Sonar Interface Module Connecters and Indicators

5.2.1. Front Panel

The front panel of MS8200 multibeam echo sounder consists of multiple indicator lights, as shown in the Figure 5.2 below.

The three indicators on the left represent PPS signal, synchronization signal and working status of the sound velocity sensor respectively. The three indicators on the right represent the GNSS differential signal, the attitude measurement equipment and the GNSS working status respectively.




Figure 5.2 Sonar Interface Module Front Panel

Below is the indicator status introduction.

Indicator	Normal Status	Abnormal Status
PPS	Blinks every 1s	Off or abnormal blinking rate
SYNC	Blinks at the rate of PING rate	Off or abnormal blinking rate
SVS	Blinks at the rate of sound velocity output rate, default is 8Hz	Off
MOTION	Blinks at the rate of attitude output rate, default is 100Hz	Off
DIF-MSG	Blinks at the rate of GNSS differential signal, default is 1Hz	Off
GNSS	Blinks at the rate of GNSS output rate, default is 1Hz	Off

5.2.2. Back Panel

The back panel of the sonar interface module is mainly composed of power module, Ethernet transmission interface, auxiliary device data interface, PPS interface, synchronization interface, GNSS antenna interface, sound velocity sensor interface and sonar watertight cable interface, as shown in the figure 5.3 and 5.4




Figure 5.3 Sonar Interface Module Back Panel




Figure 5.4 Sonar Interface Module Back Panel

The exact usage of each interface is listed as below.

Interface	Function
Status	Indicator of the device status
Earth	Connect the device with earth
On/Off	Power switch of the device
Power	Connect with DC or AC power supply
Data	Data input / output connector
Sonar	Connect with transducer
LAN1	Ethernet port to connect with display and control or navigation PC
LAN2	Ethernet port to connect with display and control or navigation PC
GNSS	Connect with external GNSS Receiver
SVS	Connect with sound velocity sensor SVS1500 for power supply and input sound velocity data
PPS	PPS signal input or output
SYNC	Synchronization signal input or output
SEC ANT	Connect with the front GNSS antenna for heading
PRI ANT	Connect with the primary GNSS antenna for position

Among them, the data interface is for extending port. Below is the introduction of the indicator status and data extending port.

Connector	Status and Function Introduction
Status Indicator	Red: Sonar Interface Module is not connected or mis-connected.
	Yellow: The device is in preparation.
	Green: The device is normal and ready to start up operation.
COM1 (GNSS COM)	External GNSS input, 9600 ~ 115200bps auto adaptive
COM2 (SVS COM)	Sound Velocity Sensor data input, the Pin 7 supports 12V power output, 9600 ~ 115200bps auto adaptive
COM3 (Extended data cable connecting out)	External RS232 data input, 9600 ~ 115200bps auto adaptive
COM4 (Extended data cable connecting out)	External RS232 data input, 9600 ~ 115200bps auto adaptive
COM5 (Extended data cable connecting out)	External RS232 data input, 9600 ~ 115200bps auto adaptive
COM6 (Extended data cable connecting out)	External RS232 data input, 9600 ~ 115200bps auto adaptive

6. System Installation and Configuration

MS8200 series multibeam echo sounder consists of underwater acoustic transducer and sonar interface module. Below we will introduce the composition of the whole system and explain the system installation involving the underwater parts and the above-water units respectively.

The components of MS8200 system are all packed in the carrying case. Figure 6.1 shows opening of the carrying case storing the main units and accessories.



Figure 6.1 MS8200 Multibeam Echo Sounder Carrying Case

6.1. Underwater Parts Installation

Underwater parts include acoustic transducer, sound velocity sensor, SVS cable and flange mount, which have been assembled in factory. Users do not need to fix by themselves. The underwater parts look like Figure 6.2.



Figure 6.2 Underwater Transducer Unit

6.1.1. Underwater Transducer Installation

Please follow the below steps to install the transducer safely.

- (1) Pass the watertight cables of acoustic transducer and sound velocity sensor through the steel pipe of the mounting bracket, and carry out the necessary anti-cut protection;
- (2) Fix the underwater transducer with adapter flange;
- (3) Connect and protect the transducer with steel cable or other strip;
- (4) Fix the mounting bracket and acoustic transducer to the ship's aside;
- (5) Tighten the steel cable or strip to prevent transducer and bracket vibration during the sounding measurement;

6.1.2. Underwater Installation Precautions

- (1) Select a suitable surveying vessel according to draft request & the hydrological conditions of the surveying water field and the size of the multibeam echo sounder;
- (2) When choosing the installing location of the acoustic transducer, consider the safety of transducer, especially the impact of underwater obstacle, wharf & shallow beach and the influence of surrounding objects (Away from propeller, water outlet and select right installation depth to avoid vessel bottom shielding) on the measurement.

- (3) During the installation process, correspondingly protect the surface of the transducer to prevent scratching by hard objects;
- (4) It is not suitable for sounding operations in areas where the water is not deep enough to prevent damage to the transducer;
- (5) It is not suitable for sounding operations when there are too many objects, such as twigs, fishing nets, in water to prevent damage to transducer;
- (6) The underwater transducer installation shall ensure solid, avoid vibration, shaking, shock or deformation;
- (7) For other precautions, please refer to the Part 3. Safety in this manual;

6.2. Sonar Interface Module Installation

Sonar Interface Module need connect with underwater transducer, display & control computer and other accessories.

6.2.1. Sonar Interface Module Introduction

(1) Sonar Interface Module:

Its connectors are shown as Figure 6.3. For details, please refer to the Part 5. Instructions for use of deck unit in this manual.




Figure 6.3 Sonar Interface Module Back Panel

(2) GNSS antenna:

Two GNSS antennas are used for attitude and heading measurement, they are as shown in Figure 6.4.



Figure 6.4 GNSS Positioning & Heading Antenna

GNSS antenna need install on magnetic mounting pole as shown in Figure 6.5.



Figure 6.5 GNSS Antenna and Magnetic Mounting Pole

(3) Display and Control Computer:

It is used to display the sounding result, control echo sounder working modes, data acquisition and navigation as shown in Figure 6.6.



Figure 6.6 Display & Control Computer

(4) GNSS Antenna cable:

It is used to connect GNSS antenna and Sonar Interface Module as shown in Figure 6.7.



Figure 6.7 GNSS Antenna Cable

(5) Power Cable:

It is used to connect sonar interface module with power supply, including DC and AC power cables, as shown in the Figure 6.8 is 220V AC power cable and Figure 6.9 is 24V DC power cable.



Figure 6.8 220V AC Power Cable



Figure 6.9 24V DC Power Cable

(6) Type 7 Dual Shielding Ethernet Cable:

Used to connect Sonar Interface Module with display & control PC, which is same as show in Figure 6.10.



Figure 6.10 Type 7 Dual Shielding Ethernet Cable

6.2.1. Sonar Interface Module Installation


- (1) Fix the sonar interface module and display & control computer in a suitable area of the cabin to prevent slipping or dropping during operation;
- (2) Connect the watertight cables of underwater transducer and sound velocity sensor to the corresponding connectors of sonar interface module;
- (3) Use the DC or AC power supply, plug the power cable into the corresponding connector of sonar interface module;
- (4) Use the Ethernet cable to connect the sonar interface module and display & control computer;

Note: For the corresponding connector information, please refer to Part 5.2.2 Back Panel.


7. How to set up RTK?

- 1) MS8200 Sonar Interface Module (Hereafter refer to SIM) connect to power supply. The LAN port connect to PC computer. At the same time, transducer is also installed underwater and connected to SIM. Then power on the power supply.
- 2) Open HydroQuest to check whether the underwater parts and the other devices on the deck is well connected. If yes, the 2 icons at the right bottom of the software will show green light (Some time, if computer is set up 2 IP address or with not only network card, it will show red, but everything still work normal).

If not connect well, power off the power supply first. Double check the hardware and network connection, make sure everything is connected correctly, then power on again.



- 3) Use NTRIPClient to set up the COM port and internet RTK parameters. If needed, please refer to NTRIPClient Manual for details.
- 4) Install the software of USR-VCOM_V3.7.1.520_Setup.exe, which is a virtual COM port software.
- 5) Open USR-VCOM to set up virtual COM port, the process is as below:
Click the left button of "Add" to set up virtual COM port.




Remarks	COM Name	Parameters	COM State	Net Protocol	Remote IP	Remote Port	Local Port	COM Received	Net Received	Net State	Reg ID	CloudID
CDM1	CDM1	Not used	Not used	TCP Server	--	--	5003	0	0	Listen	0	0

The first line is to set up Virtual COM port No., which must be the same with COM port set in Ntrip.

Second line is to set up the network protocol as TCP Server.

Both of the third line of local IP address and forth line of target port are no need to set up.

The fifth line is local port, which shall be set up as 5003.



Virtual COM: CDM1

Net Protocol: TCP Server

Local IP: 192.168.110.38

Remote Port: 20108

Local Port: 5003


Remarks:

OK Cancel Advanced -


Use D2D
Register ID 0 (?)

Use USR CLOUD [Help](#)
Cloud ID
Communication Code

After finished, click the left button of OK. And the screen change to below.



6) Then set up the COM for RTCM in Port Setting in HydroQuest as shown below.



7) Then check the bottom in HydroQuest to see the GPS Status. If where the arrow pointed at turns to be GPS Fix, it means the setting is successful and RTK works well.

If abnormal, check the setting up and repeat step 1 to 6.



7.1. How to use NTRIPClient

Double click “NTRIPClient.exe” to run NTRIP.

名称	修改日期	类型	大小
Logs	2019/12/29 星期...	文件夹	
NMEA	2019/12/29 星期...	文件夹	
NTRIPClient.exe	2016/12/19 星期...	应用程序	140 KB
ntripconfig.txt	2019/12/29 星期...	文本文档	1 KB
Settings.txt	2019/12/29 星期...	文本文档	1 KB
sourcetable.dat	2016/12/19 星期...	KMP - MPEG M...	2 KB


7.2. COM Port Setting

This is to set up the COM port to receive RTCM message, click “EDIT”



Set “Serial Port” and “Baud Rate”. The default baud rate of MS8200 RTCM setting is 38400.

Click the button of “Connect” to connect the port.




Then the screen will change to the figure shown as below.




7.3. NTRIP Setting

Click the list after “NTRIP Stream” and select RTCM30_GG.


Please be noticed that MS8200 Internal GNSS board does not support V32. So not choose V32, but choose V30, which is RTCM30.



Account Setting




After click “Edit”, then enter server setting.




Input the IP address, port, username and password.

At the location field, input the latitude and longitude in degree. Then click OK and connect to NTRIP Server:



Click button of “Connect” to finish the server connection work.


If setting up correctly, NTRIP Status will show “Connected, followed with the data size received”.



7.4. Check the Internal GPS Status

With COM port cable connecting with COM4 of MS8200 Sonar Interface Module (SIM or called Deck Unit), check the positioning status of internal GNSS board from HydroNavi.

Appendix 1 Underwater Transducer Drawing



Appendix 3 Sonar Wet Cable Definition

A End	Q'ty	Cable Length / Cable Specification	B End	Q'ty
MCIL8F (Connector Tail 20 ± 2cm)	1	15m / 10-core BASF cable	FGG.2B.310. CLAD82	1
Pin	Color	Waterproof Core Color	Pin	Signal
1	Black	Thick Black	1	GND
		Thick Blue	Empty	
2	White	Thick Red	2	VCC
		Thick Brown	Empty	
3	Red	Red White	3	ETH TX-
4	Green	Thin Red	4	ETH TX+
5	Orange	Green White	5	ETH RX-
6	Blue	Thin Green	6	ETH RX+
7	Yellow / Grey	Blue White	7	RS485B
8	Brown-	Thin Blue	8	RS485A
	Shielding		9	Shielding GND
			10 (Empty)	

Remarks:

- (1) B End need to be vulcanized after welding;
- (2) After A End is welded, it is necessary to apply thread glue, when twisting the tail clip, and encapsulate it for waterproof.